

**Unobtainium Supply Co**  
When it's NLA, who do you call?



## **MIRROR CAP INSTALLATION TIPS**

Rev. B

Effective: 06-JUL-2018

Unobtainium Supply Co.

523 Longley Rd

Groton, MA 01450

978.448.2110

[www.UnobtainiumSupply.com](http://www.UnobtainiumSupply.com)

## MIRROR CAP INSTALLATION TIPS:

The Ferrari design isn't great for retention. However, there are some things you can do to ensure they don't get lost:

1. Check to make sure the ridges in the mirror base fit fully into the grooves in the mounting tabs. If necessary use a small file to tweak the groove to ensure fit.
2. If the fit is just a bit loose, try heating it to soften the cap & expand it slightly to tighten the fit. When heated the plastic will soften & flex, then take a set when cooled. It has to be heated to at least 212F (boiling water), ~250F(oven, heat gun, or hair dryer) is even better.
3. Install with a small amount of black silicone on the tabs to ensure it doesn't accidentally come loose.